



COMMANDO
Vehicle Security

The diagram above is for years 1996-2000 but you need to add with factory security **4020 Ohm** for Lock and **665 Ohm** for Unlock. Models 2001-2002 will be **5.3K Ohm for Lock** and **2K Ohm for Unlock**.

***NOTE:** For actual resistor values please see the **Additional Info** section of the Wiring Chart for your specific vehicle.

ATTENTION: This wiring information is being provided free of charge and on an "as is" basis, without any representation or warranty. It is your responsibility to verify any circuit before interfacing with it by using a digital multimeter. GNU Industries, Inc. assumes no responsibility with regards to the accuracy or currency of this information. Proper installation in every case is and remains the responsibility of the installer. GNU assumes no responsibility resulting from an improper installation, even in reliance upon this information.